

DIRECTIONS FOR MAKING A WHITEBOARD






MATERIAL NEEDED:

- 1 – 2 x 8, 36 inches long, surfaced 4 sides
- 1 – 2 x 4, 36 inches long, surfaced 4 sides
- 2 – 2 x 3's, 8 feet long, surfaced 4 sides
- 2 – 2 x 3's, 7 feet long, surfaced 4 sides
- 1 – 1 x 8, 8 feet long, surfaced 4 sides
- 1 – 4' x 8' piece of 3/8" particle board or plywood
- 1 – 4' x 8' piece of 1/8" white showerboard*
- 1 quart of contact cement
- 4 caster wheels to suit – can be 4 swivel or 2 swivel and 2 fixed
- 4 – 1/4" carriage bolts 3 1/2 inches long
- 4 – 1/4" washers
- 4 – 1/4" nuts
- 1 – 13 5/8" x 13 5/8" piece of 3/8" plywood
- Nails or screws as needed
- Wood glue as needed

*Some showerboard has been treated with a protective coating that hinders its use as a whiteboard. If so, it will need to be made useable. Test the board by writing on it, then erasing it. If the marker smears rather than erasing, treat the board as follows:

- a. Gently wipe the entire board with lacquer thinner.
- b. Recondition the board using dry erase reconditioner. This can be purchased at most office supply stores. It is packaged in a spray bottle similar to that of dry erase cleaner.

The whiteboard should then be ready for use.



Optional pen & eraser trough - attach to bottom of ITEM C with wood screws

